

ASSEMBLY INSTRUCTIONS ROUND STYLE 30x30x15

Please read instructions completely before you begin. This will help attain the best results for your installation.

CONGRATULATIONS!

Congratulations on your purchase of a Rhino Shelter 30x30x15 Round Style Portable Building. With proper installation, use and maintenance, your new unit will provide many years of good and suitable service. Your new Rhino Shelter portable enclosure is a combination of excellent engineering and well thought out design. The unit is comprised of a rigid tubular frame, covered with a long life polyethylene cover and double door ends.

The multiple part frame assembly is pre-drilled for easy insertion of frame bolts. The tubing is made from high-grade galvanized steel., resisting moisture and oxidation over the life of the shelter. The cover and doors are made from **ASTM-5** approved polyethylene materials. The cover is UV protected for exposure to sunlight.

SAFETY WARNING

The installation of this unit must conform to the requirements of all authorities having jurisdiction in your specific local area. In the absence of such requirements, the assembly and installation must conform to the provided assembly and installation instructions. Rhino Shelter will not responsible for failure to comply with any requirements in a given local area. Damages, consequential damages, or injuries caused by improper installation, alteration, improper use, or damages caused by snow, wind, or any acts of nature are strictly that of the user. Unit is not intended for occupancy for any length of time. NO running of internal combustion engines, open flames or contact with heated surfaces is allowed.

For installation assistance or Customer Service, please call 800-447-7079 or 203-877-7070, 8AM-5PM EST. Cartons should be inspected upon delivery from carrier, and any evident damages should be noted on the bill of lading before signing. If upon opening the cartons hidden damage is discovered, contact carrier or it's agent immediately. Claims for shipping damage MUST be made with the shipping company. An inspection of the goods will most likely be required. Do not discard

packing or any components before the freight company inspection. All claims for freight damage must be made within 15 days of receipt of the goods in accordance with ICC regulations.

ASSEMBLY PROCEDURE

The proper sequence and steps to install this unit will produce a proper and good installation. Failure to read and follow these guidelines may result in an improper installation and will void all warranty and protection the owner is entitled to with the product. The steps to be undertaken are:

- Perform an inventory check before beginning, to be certain all components are available for installation.
- 2. Prepare location and place all unit boxes near location sight.
- 3. Assemble Seven (7) Arch Assemblies of unit.
- 4. Assemble unit End Arch, first Interior Arch, and Wind Braces with the first ridge crest, base, and side rail sections.
- 5. Add additional Arch Assemblies with each section of base rails and side rails.
- 6. Level and square Frame of Unit.
- 7. Anchor frame assembly to ground with provided anchors. U-bolts and drive rod.
- 8. Install Doors (2) on ends of frame assembly.
- 9. Install Main Cover over frame assembly.
- 10. Install Door Roll-up kits

TOOLS REQUIRED

The following hand tools will be needed for proper installation of your new Rhino Shelter building:


9/16 Open End Wrench
9/16 Socket or Box Wrench
Large Flat Head Screwdriver
2lb maul or Sledgehammer
2 Foot Level
12' Step Ladder
Stakes & String for squaring Frame

INVENTORY CHECK

Start installation procedure by removing all components from packaging to ensure all components are present. Inventory chart appears on the last page of this manual.



Frame Parts




Hardware



#11 / CBN-7005-4 3/8" x 4" Carriage Bolt Used on Arches and Cross Rails



#12 / CBN-7005-CW 3/8" Curved Washer Used on Arches and Cross Rails When 4" carriage Bolt is used



#13 / CBN-7005-4 3/8" x 2-7/8" Carriage Bolt Used to connect Upright Foot and Plain Upright to Arch. Also on Wind Brace to Corner Foot.





#14 / CBN-7005-W 3/8" Flat Washer Used where Wind Brace connects to frame.




#15 / CBN-7005-N 3/8" Locknut Used on entire frame with Carriage Bolts NOTE: Carriage Bolts should always be inserted from the outside of the frame, pointing in toward the interior of the frame. This will prevent the bolts from puncturing through the main cover or doors.













SITE PREPARATION

Select a level or as close to level as practical location for your Rhino Shelter Building. The building should be placed on a base of materials suitable for the storage load to be protected. The unit should not be located under trees, which will shed hard fruit such as apples, walnuts, or heavy pine cones. The cover of your unit will protect against normal falling leaves and light debris, however, large branches or other falling items may cause a puncture or tear in the cover material.

Take notice of drainage around your intended location. Water draining from the surrounding terrain should be planned so that it does not run into the unit. As well, rain or melting snow hat comes off the unit should be drained away rather than accumulate and pool around the unit. Check to be certain that adequate clearance is allowed for entry and exit from ends of the unit. As unit has doors on both ends, ideally boat or equipment can be inserted or removed from either end.

Using the stakes and string, measure off and square area for intended installation. Level the ground as best as possible.


A properly leveled frame yields maximum strength.

ARCH AND FRAME ASSEMBLY

STEP 1. ASSEMBLE THE FRONT & REAR END ARCHES AND #4 MIDDLE ARCH W/FEET (3 ARCHES)

Each ARCH consists of:

- 3 #1 CT-7006 Crest Tube-swedged end
- 1 #2 CT-7007 Crest Tube-plain ends
- 2 #3 CT-7008 Arch Side Tube
- 2 #4 EUL-7002 Arch End Upright with Foot



End Arch (and #4 arch) Assembly

Use Carriage Bolts with Washers and Nuts through pre-drilled holes in frame members. (refer to detail of arch assembly for correct hardware) Be certain to insert carriage bolts from the outside into the interior of the unit, with the washers and nuts on the inside of the frame. This will prevent the bolts from puncturing through the cover material. Do not tighten down the nuts completely until frame is fully assembled and set in place.

STEP 2. ATTACH CORNER WIND BRACES TO FRONT AND REAR END ARCHES


Attach Corner Wind Braces #6 CW-7005 to the INSIDE of EACH side of the End Arches you assembled in step 1. Refer to detail drawing for correct hardware. Do not tighten completely.

STEP 3. ASSEMBLE THE REMAINING (4) FOUR INTERIOR ARCHES

Each INTERIOR ARCH consists of:

- 3 #1 CT-7006 Crest Tube-swedged end
- 1 #2 CT-7007 Crest Tube-plain ends
- 2 #3 CT-7008 Arch Side Tube
- 2 #5 EUL-7003 Arch End Upright -plain base

Use Carriage Bolts with Washers and Nuts through predrilled holes in frame members. Refer to detail drawing for correct hardware. Be certain to insert carriage bolts from the outside into the interior of the unit, with the washers and nuts on the inside of the frame. Do not tighten down the nuts completely.




Arch Assembly, for arches #2, #3, #5, #6 (Arches without foot)





STEP 4. START COMBINING ARCH SECTIONS TO BUILD FRAME

Stand first End Arch Assembly up and support with the wind brace temporarily. Attach #7 ECR-7003 Plain End Cross Rails to the inside of the End Arch Assembly




using 4" Carriage bolts, washers and nuts through the pre-drilled holes. Again do not tighten down completely. Always remember to insert bolts from the outside into the interior to prevent damage to cover.



Stand an Interior Arch Assembly (without feet) assembly into place about 60" from end arch assembly. Align holes in Arch with Cross Rails. Using 4" Carriage Bolts, with nuts and washers connect the Side Cross Rails between the arches. Connect Wind Brace from End Arch Assembly To first Interior Arch. This will make the first two arches self-supporting. Insert next Cross Rail into the base and Side Rails for the next arch assembly.

STEP 5. TOP RIDGE CREST CROSS RAIL

Begin the Top Ridge Crest Cross Rail by placing the first end UNDER the End Arch Assembly, secure loosely with carriage Bolt CBN-7005-3, with washer and nut facing interior of unit.




STEP 6. CONNECT ADDITIONAL ARCHES

Add Interior Arch Assembly #3 to the first two arches assembled in Step 4. The Top Ridge Crest Cross Rail (only) will be UNDER the End Arches and OVER the Interior Arches (see Illustration). All the other Cross Rails will be on the inside of the frame. Interior Arch Assembly #4 (Middle Arch) with feet is put on in the middle of the frame support.



Interior Arch Assembly #5 and #6 have plain feet ends. The last Arch #7 will be the remaining End Arch Assembly with feet. Make certain to install the Wind Braces between the End Arch Assembly (#7) and the





first Interior Arch Assembly (#6) to complete the frame assembly.

DO NOT completely tighten down bolts that connect the Cross Rails to the END ARCHES, they must be removed for End Panel Zippered Door Installation.

STEP 7. LEVEL AND SQUARE FRAME

Align the first side of the building arch assemblies using a string. This should be the permanent position desired for the building.





Measure the base span of each arch, side to side. The outside of the arch bases should be 30'. Too wide a span will weaken the frame resistance to load, such as snow, and prevent the doors and main cover from fitting properly. Adjust each arch to the correct width, using the first side aligned above.

Measure diagonally from inside corner to inside corner of frame. Both diagonal measurements should match. Adjust frame and support as necessary to bring frame into square. Failure to square frame will result in poor cover fit and 'educed strength and rigidity. Frame should be 30' side to side and 30' front to back – Outside Dimensions.





30' Length and 30' Width Outside Dimensions



PROPER BASE SUPPORT

The weight of the building will rest on the base of the arch uprights and feet. If the ground is not hard, support the legs with a patio block or brick to prevent sinking into the earth or settling afterwards.



MAINTAINING FRAME POSITION

To help hold the frame in place and square, insert a piece of rebar or landscape stake into the hole in the end and center arch feet into the ground. This will help keep the frame square, and prevent the ends from spreading and straining the zippered doors.



Step 8. TIGHTEN CARRIAGE BOLTS

Once frame is square and leveled and properly supported, tighten down carriage bolts. Do NOT over tighten. Do not oval or otherwise crush tubing pieces. Do not tighten cross rails on end arches or wind braces until after doors are assembled.





Insert PLASTIC END PLUGS #EP-1000 & #EP-1001 into all open ends of frame members.

ANCHORING FRAME TO GROUND

NOTE: Frame must be anchored before installing any doors or cover.

Once frame is square and properly supported, tighten carriage bolts on all frame members, except for End Arch members to Cross Rails along base, side, and top. Do not over tighten or oval tubing. After hardware is tightened, insert plastic end plugs #14 (2 3/8") & #15 (1 1/8") into all open ends of frame members.

NOTE: Frame <u>must</u> be anchored before installing any doors or cover.

Each Rhino Shelter 30x30 building comes with 14 EARTH CABLE ANCHORS (DBA-3000) with U-bolts and nuts. These versatile anchors allow the frame to be secured to almost any surface. In addition a 36" DRIVE ROD (DR-3001) is included to drive the anchor heads into the earth. Anchor placement should be on the inside of the unit, at each corner and at the base of each upright leg pole. This will prevent unit frame from spreading over time.

If the location where you are placing the building has very hard ground or <u>any</u> rock in it, pre-drill the holes before inserting anchors. Hammer drills can be rented at most home improvement or rent-all centers. Hitting the anchors into rock will cause the drive rod end to mushroom inside the anchor head, and prevent the drive rod from coming out of the hole.


Anchor placement should be made <u>inside</u> the frame at the interior corners of the unit, and midway along the sides of the frames. Anchors secure the building to the ground, as well as prevent spread of the frame over time.



Pre-Drill Holes if there is Any Rock In Ground



Drive Rod inserts into Anchor Head





ANCHOR STEP 1

Place the drive rod provided into the cup of the anchor. Using a heavy hammer drive the anchor into the soil until 6-8 inches of cable remains above the earth. Remove drive rod.

ANCHOR STEP 2

Place the Drive Rod through the loop in the anchor lanyard. Pull upward to set anchor head into the ground.



ANCHOR STEP 3

Slip one side of the U-bolt through the eyelet at the end of the anchor cable. Attach the cable to the Arch leg upright with the U-bolt and tighten. Do not attach to base cross rails. Ensure there is no slack in the cable. Slack can be removed by wrapping the cable around the tiedown rail.



Step 8 - End Panel Installation

Note: Both End Panels MUST be installed before installing Main Cover onto frame.

STEP 1. Remove Carriage bolts from the Top Crest Rail and the two Upper Cross Rails. Install one #14 End Panel Door w/Zippers at a time to the Frame assembly.

STEP 2. Place the end panel over the first arch and wrap the material around the arch bringing the slits in the end panel to the inside of the frame arch. End Door Panels have pre-cut slits that allow frame members to pass through so rope pocket is inside unit. Place the top ridge pole and the side cross rails through the material slits and replace the carriage bolts and tighten. The door end will also require removal of the wind brace bolts and placement of the wind braces through slits in the ends panel. Reconnect wind braces with carriage bolts once end panel is put into place.







End Panel / Doors have pre-cut slots that allow Cross Rails to pass through, so material can wrap around arch with rope pocket inside unit

END PANEL/ZIPPERED DOOR INSTALLATION

NOTE: End Panel/Doors <u>MUST</u> be installed BEFORE Main Cover. Also required for Building Strength.

STEP 1. PREPARE FRAME MEMBERS

Remove the Carriage Bolts holding the Top Crest Cross Rail and Side Cross Rails to the End Arch. (these are the ones you left loose). Bring the Door Panel up to the outside of the frame arch, keeping the white side in, colored side out. Align the material evenly over the arch so bottom is slightly off ground.

STEP 2. ATTACH END DOOR PANEL

Wrap the edges of the panel around the frame arch, bringing the slits in the panel, to the inside of the frame.

Thread the Top Ridge and Side Cross Rails through the slits and re-attach to the frame arch using carriage bolts, with nuts and washers facing inward as always. Tighten down.

Each End Panel/Door will also require removal of Wind Brace bolts, and placement of Wind Brace through slits in End Panels. Remember to reconnect Wind braces with carriage bolts and tighten down, once End Panel is in place.






STEP 3. TIGHTEN AND SECURE END PANEL/DOOR

Tie off one end of the rope coming out of the end panel to a TURNBUCKLE (turnbuckle should be loosened all the way), and attach the turnbuckle to the hole in the Corner Foot of the End Arch. Grab the other end of the rope and apply downward pressure with your foot to tighten the fabric around the arch and remove excess slack. Re-adjust gathered material evenly along frame arch, this step is key to getting a good door fit.





Tie off that end of the rope to a turnbuckle (fully opened) attached to that Corner Foot. The End Panel / Door can then be tightened further by adjusting the Turnbuckles.

NOTE: Adjust the end panel / door by turning the turnbuckles or repeating step 3 till taut.



Adjust the door panel so that the edges do not come in contact with the ground. Cut the Slits as Needed To Adjust the Door Edge Off the Ground. Put an Electrical EMT or Pipe into the bottom edge to put weight on the door fabric.

Repeat Installation for other End Panel / Door.



The Rope Pocket should be located inside the unit with frame members passing through the pre-cut slots. Replace carriage bolts after putting the end panel in place.

When putting on the doors, adjust the length to make certain the doors do not drape onto the ground. If pulling them up puts too much stress on the slit where it goes over the wind brace, use a sharp knife to cut slit another inch or two to relieve it. The PE fabric is rip-stop weave, and can easily be cut to relieve stress at the frame members.

MAIN COVER INSTALLATION

STEP 1. To elongate the life of Main Cover, put a small square of duct tape (field supplied) over each bolt head on frame that comes in contact with cover. The tape acts as a cushion to avoid rubbing damage to the cover over years. As an alternative, foam rubber pipe insulation makes a good cushion between the bolt heads and the main cover as well.





MAIN COVER INSTALLATION

Step 1. To elongate the life of Main Cover, put a small square of duct tape (field supplied) over each bolt head on frame that comes in contact with cover. The tape acts as a cushion to avoid rubbing damage to the cover over years.

Unpack the Main Cover from the protective plastic packaging. The line of grommets on the inside (white) of the cover on the tie down Flap run parallel to the sides of the frame assembly for positioning. Once cover is oriented properly to the Frame Assembly, pull Main Cover over frame assembly from the side, being careful not to snag the cover on any member, bolt, or other obstruction. Center the Main Cover over the Frame Assembly with the Main Cover colored side showing from the outside of the unit.

Step 2. Loosen the 4 ratchets. Place the hook that is attached to the ratchet strap into the outer hole in the foot of each end arch.



Step 3. It is important that your cover is laying square over the frame before you start ratcheting down the cover. Once the cover is even on all four sides, slowly start ratcheting down all four corners.

Warning: Do not over tighten the ratchet straps.

Pay close attention to how tight the cover is put onto the frame. It should be tight enough so it does not flap around in the wind, but not so tight that it tears the material cover. The fabric backed PE fabric of Rhino Shelter units does not stretch. If you pull it so tight that

the fabric is stretched, a small amount of additional stress from wind or contact can cause premature tears and material failure. Only tighten cover enough to remove valleys between arch assemblies. Do <u>Not</u> over tighten.

Once the ratchet starts becoming harder to tighten stop so you do not damage the cover.





Step 4. When the cover is completely aligned secure the cover to the bottom tie-down cross rail using the rope provided. Start at one end and tie off the rope to the cross rail. Lace the rope through the grommets in the cover and back under the tie-down cross rail. Repeat this on the opposite side.






BOTH THE COVER AND END PANELS SHOULD BE CHECKED AND TIGHTENED ON A MONTHLY BASIS.

You can now install the Door Roll-up Kit that was provided with your unit. Your kit is meant for ONE end, two doors. You can purchase an additional kit for the other end if desired from our Customer Service Department 1-800-447-7079 or our website www.mdmproducts.com



COMPLETED STRUCTURE



The roll up door kit rollers should be positioned along the width of the door equal form both ends.



Place the two-piece rail into the base pocket of the doors for weight and rigidity to roll easily.





Maintenance and Care

Annually or more often, the unit should be completely inspected internally and externally to make certain the unit remains properly installed and secured. Particular attention should be paid to:

<u>Hardware</u> – check all carriage bolts and hardware connectors to be certain they are in place and tightened.

Anchors – during normal weather trends, the unit will strain against the anchors under windy conditions. Anchor hardware connection to frame members should be maintained tight and depth of anchors should be checked to be certain they remain deeply and firmly set.

Snow Accumulation – All snow accumulation on the main cover should be removed as soon as possible. Tap the main cover from the inside with a broom or soft brush to clear cover. Unit is not designed for any amount of accumulated snow or ice. Warrantee does NOT cover damage due to snow accumulation.

Main Cover Lacing – the poly rope that secures the main cover to the bottom rail of the frame assembly should be checked, and adjusted as needed. The tension on the main cover should be uniform from end to end and side to side. Rope ends must be tied off onto the frame members at the ends on each side.

<u>Turnbuckle Adjustment</u> – during normal wind conditions and load, the doors and main cover adjustment points at the turnbuckle should be checked and tightened as necessary. The turnbuckles should be neither completely extended nor taken up, so that turnbuckle should be tight when in the mid range of overall adjustment. If necessary, readjust rope tie off on turnbuckle as needed to tighten or loosen as needed.

<u>Cleaning</u> – cover and doors can be cleaned with a mixture of light detergent and water. A soft bristle brush with the mixture can be used to loosen any hard dirt, mold, or buildup on the cover. After cleansing, the cover should be rinsed thoroughly to avoid any chemical reaction from residual detergent. <u>Allowing dirt and debris to sit on cover over an extended time will damage cover irreparably.</u>

<u>Severe Weather</u> – in preparation for inclement weather, completely secure the doors on both ends of your Rhino Shelter portable building. Allowing wind to enter either end lifts the building and puts undue stress on the anchoring system. This also shortens the life of the doors, zippers, and main cover.

<u>Door Operation</u> – **Every time** doors are put down the zipper must be pulled down completely, and the snap buckles <u>MUST</u> be put together and adjusted. Failure to do so will cause door zipper to fail prematurely. Door area is so large that wind can pull zipper apart if the snap buckles are not adjusted to take the stress of wind.

Customer Service or Installation Assistance

Please call MDM Products at 800-447-7079 or 203-877-7070 for questions about the proper installation of the unit in any way. Care and attention to a proper installation will add many years of life and function to your Rhino Shelter unit.

Please retain purchase documentation for your Rhino Shelter unit. All warranty claims must include purchase documentation for verification. All parts on your Rhino Shelter unit are available for replacement as needed. Protect your purchase by completing warranty registration card and mail/fax as soon as practical after installing your unit.

Thanks again for choosing this quality product. With proper operation and care we are confident it will meet your expectations in functionality, appearance and longevity.



INVENTORY CHART

Item Number	Part Number	Description	Qty
1	CT-7006	Crest Tube – Swedged End	21
2	CT-7007	Crest Tube – Fem X Fem	7
3	CT-7008	Arch Side Tube	14
4	EUL-7002	Arch End Upright w/Foot	6
5	EUL-7003	Arch End - Plain	8
6	CW-7005	Corner Wind Brace	4
7	ECR-7003	End Cross Rails – Plain Ends	7
8	SCR-7004	Cross Rail Pieces – swedged one end	35
9	EP-1001	End Plug 1"	14
10	EP-1003	End Plug 2-3/8"	6
11	CBN-7005-4	Carriage Bolt – 3/8"X 4"	49
12	CBN-7005-CW	Curve Washer – 3/8"	55
13	CBN-7005-3	Carriage Bolt – 3/8"X 2-7/8"	14
14	CBN-7005-W	Flat Washer- 3/8"	8
15	CBN-7005-N	Locknut 3/8"	63
16	TB-3004	Galvanized Turnbuckles	8
17	R-7003	3/16" Rope	2
18	DBA-3000	Earth Anchor Cable Anchors	14
19	UB-3002	U Bolt w/ Nuts	14
20	DR-3001	36" Steel Drive Rod	1
21	**	Door Bottom Pipe 1" X 72" Plain End	2
22	**	Door Bottom Pipe 1" X 72" Swedged One End	2
23	**	Roller Pulley	4
24	**	Rope for Door ¼" X 49'	2
25	**	Bolt ¹ / ₄ "X 1-3/8"	2
26	**	Self Tapping Screw ¼"X ½"	2
27	**	Tie Off Rope Cleat	2
28	MUC-7000	Main Cover	1
29	TZD-7002	End Panel Door – Triple Zipper	2

^{** -} Parts included in Roll Up Door Kit